


REFURBISHMENT OF BRICKWORK – EXPOSED TO WATER PRESSURE

Constructed in masonry or concrete



Application Instructions

- 1 Install a horizontal damp-proof course with VANDEX INJECTION MORTAR (VIM) or VANDEX IC.
- 2 Optional: Treat substrate with VANDEX MINERALIT depending on substrate condition.
- 3 Chisel out a reglet (approx. 30 × 30 mm) along the slab/wall junction and point with VANDEX UNI MORTAR 1 Z.
- 4 Apply an open textured VANDEX ROUGH CAST covering 50 % of surface, as a bonding bridge.
- 5 Apply VANDEX LEVELLING PLASTER as a levelling and salt inhibiting plaster.
- 6 Apply VANDEX REFURBISHMENT PLASTER white as final aesthetic lining.
- 7 Apply appropriate Vandex surface waterproofing product to floor slab.
- 8 Apply a layer of sand cement render (3:1) approximately 10 mm thick, followed by two layers of VANDEX BB 75 Z. Alternatively, apply one layer of VANDEX UNI MORTAR 1 Z or VANDEX BB 75 Z.
- 9 Apply the Vandex refurbishment plaster system.

Remarks:

- Substrate adhesion strength > 1.5 N/mm²
- Salt treatment depending on salt analysis results

For further technical details and consumptions refer to technical data sheet or consult a technical Vandex representative.

The information contained herein is based on our long-term experience and the best of our knowledge. We can, however, make no guarantee since for a successful outcome, all circumstances in an individual case must be taken into consideration. Indications of quantities required are only averages which in certain cases might be greater.