


PIPE INLETS – REMEDIAL WORK



Application Instructions

- 1 Chisel out concrete around the leaking pipe to a depth of approximately 30 – 50 mm. Stop water leaks in accordance with the specification 'Plugging water leaks'.
- 2 Apply a layer of Vandex epoxy adhesive around pipe (subject to adhesion pre-test), broadcast dry quartz sand onto still wet epoxy glue, as a bonding key to the subsequent patching mortar.
- 3 Patch the cavity preferably with VANDEX UNI MORTAR 1 or other non shrink mortar.
- 4 If further movement is expected, apply two coats of VANDEX BB 75 E.

Remark:

- Substrate adhesion strength > 1.5 N/mm²

For further technical details and consumptions refer to technical data sheet or consult a technical Vandex representative.

The information contained herein is based on our long-term experience and the best of our knowledge. We can, however, make no guarantee since for a successful outcome, all circumstances in an individual case must be taken into consideration. Indications of quantities required are only averages which in certain cases might be greater.